Prepare Your RV For Winter

Clean & Empty	 Deep clean interior of dirt, grime, & crumbs Clean the refrigerator, freezer, & defrost Remove foods & liquids Store bedding & other items in latching bins Clean exterior & awning Remove all valuables from interior & cargo
Inspect & Fix	 Inspect interior plumbing, & seals Inspect the seals around the interior windows, doors, ceiling vents, & around slides Inspect exterior for bad seals, cracks, leaks (roof, windows, doors, slides, underbelly, & cargo) Inspect & seal for rodent intrusion
Winterize	Winterize the following: RV plumbing system Engine, generator & batteries RV refrigerator & ice maker RV washer & dryer
Park & Secure for Storage	Park on a dry & level surface (covered areas are best) Avoid parking under tree limbs or in tall grassy areas Chock the wheels & use leveling blocks if needed Inflate tires to manufacturer max cold pressure Cover the tires Shut off electrical switches, appliances, and LP supply Remove battery & store in warm place with maintainer Close & lock windows, ceiling vents, cargo doors Close shades & curtains Place moisture absorbers Place mouse traps or repellent Cover external outlets & openings Top off gasoline or diesel & add fuel stabilizer
Rontine Check	 Check for leaks, rodents, theft Condensation, mold or mildew Battery charge Tire pressure & flat spots Use dehumidifier Check roof from branches, snow & ice